



2027MY



235HB

OWNER'S MANUAL

Dear World Cat™ Owner:

Thank you for being our customer. Welcome aboard!

We wish to take this opportunity to sincerely thank you for putting your trust in our boat building team and becoming the newest member of the World Cat Family.

The following manual is designed to ensure you enjoy your new World Cat for many years to come. We have made every effort to ensure you and your family are safe, enjoy the unique features of a World Cat, and continue to love the World Cat ride that no other boat company can offer.

If you should ever need assistance with the care, maintenance, or operation of your boat, then please visit our website at WorldCat.com to find contact information for your nearest Factory Authorized Dealer.

Once again, thank you for becoming a part of our family.

Best Regards,



ANDREW BROWN
CEO



1090 West Saint James St. Tarboro, North Carolina 27886

TABLE OF CONTENTS

Chapter 1: Customer Information	5
1.1 Owner's Portfolio.....	5
1.2 Warranty Information.....	5
1.3 Dealer's Responsibilities	5
1.4 Owner's Responsibilities	6
1.5 Manual Legend	7
Chapter 2: Boat Information.....	8
Chapter 3: Boat Specifications	9
3.1 235HB Standard Boat Specs	9
3.2 235HB Standard and Optional Features.....	10
Chapter 4: Safety and Regulations	10
4.1 Operator Responsibilities	10
4.2 Registration	10
4.3 Coast Guard Required Safety Equipment.....	10
4.4 Recommended Safety Equipment	11
4.4.1 Capacity Information	11
4.5 Pollution Regulations.....	11
4.6 Boating Safety Guidelines.....	12
4.6.1 Pre-Departure	12
4.6.2 Launching	12
4.6.3 Underway (See Chapter 5 on Performance)	12
4.6.4 Returning.....	13
4.7 Trailering.....	13
4.8 Anchoring.....	13
4.9 Shallow Water.....	13
4.10 Emergency Situations.....	14
4.10.1 Emergency Stop Switch.....	14
4.10.2 Communication.....	14
4.10.3 Rendering Assistance.....	14
4.10.4 Reporting Accidents.....	14
4.10.5 Weather	14
4.10.6 Towing.....	14
4.11 Carbon Monoxide (CO)	15
Chapter 5: Performance	16
5.1 Overview	16
5.1.1 Engine Start/Stop Procedure	16
5.2 Motor Trim.....	16
5.2.1 Bow Up Condition	17
5.2.2 Bow Down Condition.....	17
5.3 Engine Controls.....	17
5.4 Steering Controls	17
5.5 Steering Maintenance - Yamaha Digital Electric Steering.....	17
5.6 Handling Characteristics	18
5.6.1 Turning Characteristics	18
5.6.2 Adverse Sea Conditions.....	18
5.6.3 Cross-Clutching - Twin Engines	19
5.6.4 Get the Boat on Plane.....	19
5.6.5 Keep the Boat Level (if the seas change or people move on the boat).....	19
5.6.6 Handling Different Sea Conditions	19
5.6.7 Boating Tips.....	19
5.7 Performance Factors	20
5.7.1 Engine Efficiency	20

5.7.2	Propeller Condition	20
5.7.3	Weather Conditions	20
5.7.4	Load	20
5.7.5	Marine Growth.....	20
5.7.6	Bottom Paint	20
Chapter 6:	Systems Information	21
6.1	Overview	21
6.2	Fueling Guidelines.....	21
6.2.1	Before Fueling	21
6.2.2	During Fueling.....	21
6.2.3	After Fueling.....	21
6.3	Fuel System.....	22
6.3.1	Fuel System Benefits	22
6.3.2	Fuel Tank.....	22
6.3.3	Fuel Vent	22
6.3.4	Fuel Distribution System	23
6.3.5	Filling Fuel Tanks.....	23
6.3.6	Pressure Relief Fuel System Diagram.....	24
6.3.7	Troubleshooting Tips	24
6.3.8	Integrated Fuel Demand Valve Components	24
6.4	Ethanol-blended Fuel.....	25
6.4.1	Additives	25
6.5	Electrical System.....	25
6.5.1	Battery System	25
6.5.2	Battery Distribution.....	25
6.5.3	Emergency Parallel	25
6.5.4	24 Hour Circuits.....	26
6.5.5	Fuse/Breaker Locations.....	26
6.6	Battery Selection.....	27
6.6.1	Battery Care	27
6.6.2	Safety	27
6.6.3	Exposure.....	27
6.7	Wiring and Circuit Protection	28
6.8	Control System	28
6.9	Dash Switch Panel.....	29
6.10	Hardtop Switch Panel	29
6.11	Accessories	30
6.11.1	Navigational Lights	30
6.11.2	Courtesy Lights.....	30
6.11.3	Hardtop Lights.....	30
6.11.4	Livewell Lights	30
6.11.5	Bilge Pump / Float Switch	30
6.11.6	Seacocks	31
6.11.7	Raw Water Pump.....	31
6.11.8	USB Outlet	31
6.11.9	Horn	31
6.11.10	VHF System	31
6.11.11	Fusion Apollo MS-RA670 Marine Stereo.....	32
6.11.12	Plumbing System	32
6.11.13	Livewell and Livewell Pump	32

6.11.14 Fishbox and Fishbox Pumps.....	33
6.11.15 Fresh Water and Fresh Water Pump (Option).....	33
Chapter 7: Maintenance and Service	34
7.1 Overview	34
7.2 Gelcoat Maintenance	34
7.2.1 Cleaning	34
7.2.2 Waxing.....	34
7.2.3 Repair	35
7.3 Bottom Paint.....	35
7.4 Upholstery	36
7.5 Trim / Plexiglass / Polyethylene	36
7.6 Stainless Steel / Aluminum	36
7.7 Bilge Compartments	36
7.8 Cockpit Drains.....	36
7.9 Winterization	37
7.10 Maintenance Schedule.....	38
7.11 Maintenance Log.....	39
Chapter 8: Hurricane Preparedness Customer Checklist.....	40
Chapter 10: 235HB Diagrams	47
10.1 Thru-Hull Locations	47
10.2 Hose Plumbing	48
10.2.1 Fresh Water Plumbing (Option)	48
10.2.2 Raw Water Plumbing	49
10.2.3 Drain Plumbing.....	50
10.3 Battery Cable Layouts.....	53
10.4 Systems Overview	56
Chapter 11: Reference Material	60
235HB System Locations.....	60
Replacement Parts	62

Chapter 1: Customer Information

1.1 Owner's Portfolio

To help you enjoy the many features, benefits, and accessories on your new World Cat, we have provided you with the following materials:

- World Cat Owner's Manual (model specific)
- Vendor Supplied Manuals for various accessories
- Delivery Checklist
- Warranty Information

We refer to this package as the Owner's Portfolio, and will reference it often throughout this text. The portfolio contains a wealth of information, including advice on safety, operation, performance, maintenance, and warranty. Reading and maintaining this information is extremely important, and could be the difference between a positive and negative experience on the water.

1.2 Warranty Information

Upon purchasing your new World Cat, your dealer is responsible for completing the warranty card and returning a copy to the factory. The Dealer should provide you with a copy to keep in a secure place so it can be referenced quickly in the event of a warranty issue. The 10 year limited hull warranty is transferable, and a copy is included at the back of this manual should you decide to sell your boat.

1.3 Dealer's Responsibilities

Our dealers are an extension of the factory and we expect them to provide you with great customer service to help prepare you for a positive ownership experience. Therefore, we set forth a list of responsibilities for our dealers as follows:

- Provide courteous service and explanation of the product prior to the sale.
- Provide sea trials for potential owners.
- Provide a detailed orientation of your boat's features and general operation upon delivery, including safety and performance.
- Complete and sign delivery checklist.
- Explain, complete, and submit all warranty information in a timely manner after the purchase.
- Provide the customer with the Owner's Portfolio and explain the information included therein.
- Provide service after the sale, or help the customer locate a qualified service shop at home or away.

1.4 Owner's Responsibilities

As an owner you should also take an active part in the delivery and safe operation of your new catamaran. Some of your responsibilities are:

- Study and understand the limited warranty information.
- Read all literature in your Owner's Portfolio and operate the vessel in accordance with those instructions.
- Perform a walk through prior to the final delivery and ensure that the systems are functioning properly.
- Maintain the boat and perform service according to the instructions in this manual, including the 20 hour inspection for the vessel and engines.

It is your responsibility to return your boat to an Authorized World Cat Dealer for warranty work. In the event there is no World Cat dealer within a 100 mile radius of your boating location, it is your responsibility to present the boat to a marine professional in your area as directed and approved by World Cat.

Once your warranty information is processed, World Cat will maintain a record of your boat using the Hull Identification Number (HIN), which is located on the starboard side of the transom. Information regarding the dealership, owner, and the factory installed accessories will be recorded to help you should a problem arise. Also, you will receive a survey to rate your purchasing experience and the initial impressions of our company. We ask that you join our family of owners and let us know your feelings about the purchase and the quality of our product.

1.5 Manual Legend

Throughout this manual you will encounter signals to alert of important information. Text printed in bold letters and the warning system shown below is of particular importance. Please review this information prior to reading the manual.

!!! DANGER

This symbol alerts you to hazards or unsafe practices which will cause extensive property damage, severe personal injury or death if the warning is ignored.

!!! WARNING

This symbol alerts you to hazards or unsafe practices which can cause extensive property damage, severe personal injury or death if the warning is ignored.

!!! CAUTION

This symbol alerts you to hazards or unsafe practices which can cause personal injury or property damage if the warning is ignored.

NOTICE

This symbol is not hazard related. It contains information on installation, operation, or maintenance which is needed to ensure the proper operation of your boat.

Chapter 2: Boat Information

Please fill out the following information and leave in this manual for reference. This information will be important for your Authorized Dealer to provide fast and accurate service. To locate an authorized dealer call 866-485-8899 or email service@worldcat.com.

BOAT	
Model:	HIN:
Purchase Date:	Delivery Date:
Ignition Key #:	Door Key #:
ENGINES	
Make:	Model:
Serial # Port:	Serial # Stbd:
Propeller Make / Model:	Propeller Diameter / Pitch:
TRAILER	
Make:	Model:
Serial # Port:	Serial # Stbd:
DEALER	
Name:	Salesman:
Dealer Phone:	Service Manager:

235HB

THE ONLY HYBRID FOR ALL WATERS.
FISH HARD. CRUISE EASY.



LENGTH OVERALL

22' 7"

BEAM

8' 6"

FUEL CAPACITY

89 gal

DRY WEIGHT

5,100 lbs



DRAFT

9"

Engines are only available in white in 2027MY.

SPECS

LOA: 22' 7"
Molded LOA: 22' 7"
Beam: 8' 6"
Draft: 9"
Gunwale Height: Aft 23"
Transom Height: 21.5"
Dry Weight w/ Power (Approx.):
5,100 lbs (w/Twin 115's)
Max HP Rating: 300 HP (2 x 150)
Fuel Capacity: 89 gal (2 x 44.5 gal)
Freshwater Capacity: 10 gal
Livewell Capacity: 20 gal
Cockpit Length: 24"
Max Capacity: 10 Persons
Typical WOT*: 51.6 mph / 1.6 mpg



HIGHLIGHTS

- Features a remarkably skinny 9" draft
- Port and starboard in-floor 170-quart insulated fish boxes with overboard drains
- Offers comfortable seating for ten

* Includes max power and typical options. (Yamaha F150HP Twin)

FEATURES

Hull

- Self-Bailing, Non-Skid Fiberglass Cockpit Liner
- Heavy-Duty Rub Rail with Stainless Steel Insert
- Below-Deck Rigging Tubes for Electronics and Additional Batteries

Bow

- Lounger with 310 qt Storage with Shurhold 5 gal Bucket Base
- Port and Starboard 170 qt Insulated Floor Fishboxes w/ Overboard Discharge Pump (aft)
- Bow Area Cushioned Seating for 5 Adults with Integrated Grab Rails
- Through-Bolted Stainless Bow Eye
- (7) Through-Bolted Stainless 8" Cleats on Deck
- Trolling Motor Ready
- (2) Combo Rod Holders
- (2) XL Tumbler Drink Cupholders for Console Lounger
- (2) Standard Drink Holders for Console Lounger

Helm

- Fiberglass T-Top w/ Spreader Light
- Hydraulic Tilt Steering
- Acrylic Windshield
- Leaning Post w/ Rocket Launchers & YETI Cooler, Under Seat Storage, 2 Cup Holders
- Dual Ram Hydraulic Steering with a 13.5" Stainless Steering Wheel and Power Knob
- Single Garmin GPSMAP 1243xsv 12" Multi-Touch Widescreen Chartplotter / Sonar Combo, & ICOM M330G VHF

- Premium Marine Entertainment System w/ (4) JL Audio Speakers & Bluetooth
- (3) Dash Drink Holders: (1) Regular, (2) Large
- Marine Grade Switch Panel with Waterproof Switches
- Raw Water Washdown
- (2) Stainless Grab Handles on the Lounger Seat
- 1-Shelf Storage System Under the Helm
- Recessed Tray in Dash Brow
- 4 Tray Tackle Storage

Stern

- (2) Gunwale-Mounted Stainless Steel Rod Holders
- (2) Combo Rod Holders
- Cockpit Horizontal Rod Racks for 4 Rods
- Aft Deck Non-Skid Casting Platform
- Flip-Up Aft Seat
- 20 gal Livewell, Lighted with Overboard Drain and Fiberglass Lid
- Dual Batteries with On/Off Parallel Switch
- (2) 44.5 gal Polyethylene Fuel Tanks
- (2) Fuel/Water Filters
- (2) Fuel Fills with Internal Vents
- (2) 1100-GPH Automatic Bilge Pumps
- User-Friendly, Commercial-Grade Dive Ladder & Swim Platform

OPTIONS

Engine Packages

- Yamaha T/F115XB Package (White)
- Yamaha F150XSA2 Engines (White)

Hull Colors

- Arniston Gray
- Ice Blue
- Coastal Blue
- Shackleford Sand
- Annapolis Blue

Available in:

- Full-Hull or Two-Tone Hull Color

Hardtop Underside Colors

- Arniston Gray
- Ice Blue
- Coastal Blue
- Shackleford Sand
- Annapolis Blue

Bootstrapping

- Stardust (Top) & Black (Bottom)
- Dark Red (Top/Bottom)
- White (Top/Bottom)
- Black (Top/Bottom)
- Dark Blue (Top/Bottom)
- Stardust (Top/Bottom)
- Teal (Top/Bottom)

Accessories

- Edson Wheel-14.5" Satin Finish with Power Knob
- Fresh Water Shower in Transom (10 gallon Capacity)
- Quick Release Fender Holders (4)
- Forward Facing Removable Bow Backrest
- Ski Tow
- Removable Bow Table

Electronics

- Additional 12" Garmin Display
- Stereo Upgrade (400W Amp and 6.5" M6 Series Speakers)

Outriggers

- GEMLUX Deluxe Outrigger System with 18' Collapsible Hybrid Poles

Top

- Black Powdercoated T-Top and Leaning Post Frame



Chapter 4: Safety and Regulations

4.1 Operator Responsibilities

Prior to enjoying your World Cat, it is important to read and understand all the information detailed in your Owner's Portfolio. Knowing how to operate and maintain the systems on your vessel can make your experiences safe and enjoyable, as well as increase the performance and longevity of your boat. Federal law and most state laws clearly indicate that it is the operator's responsibility to maintain their vessel, and to operate it in a manner which protects the safety of their passengers and others.

This manual will provide you a basic understanding of boating practices; however, we recommend all owners review federal, state, and local regulations regarding safety and traffic prior to using your World Cat. The U.S. Coast Guard Auxiliary and U.S. Power Squadrons offer excellent educational opportunities on a local level and are open to anyone.

Boating Education Hotline	1-800-336-BOAT (2628)
U.S. Coast Guard Boating Hotline	1-800-368-5647

4.2 Registration

Vessels are required by federal and state law to be registered in the state where they are primarily used. Registration numbers and validation stickers must be displayed per regulations, and a certificate of registration must be on board while the vessel is being operated. When traveling away from your home waters, contact authorities at your destination to determine if any additional registration is required. Some areas require permits or temporary registrations to operate in their waters. When completing registration forms you will be asked for the Hull Identification Number (HIN). On your World Cat, the HIN is located on the starboard side of the transom. This number is unique to your boat and will be important for registering your vessel, as well as communicating with your dealer and our service department. Including this information in any correspondence or conversations will help our support network serve you better.

4.3 Coast Guard Required Safety Equipment

Once you have reviewed safe boating guidelines and filed for registration, it is time to equip your vessel. The U.S. Coast Guard's (U.S.C.G.) list of required equipment is shown below. To review the guidelines for each item, go to <https://www.uscgboating.org/images/420.PDF>.

- Audible Signaling Device (Bell, Horn, or Whistle)
- Fire Extinguisher
- Navigation / Anchor Lights
- Personal Flotation Devices (PFD's)
- Visual Signaling Devices

NOTICE

Remember to check with state and local agencies to ensure that additional items are not required to operate your boat in their waterways.

4.4 Recommended Safety Equipment

Although not required, there are several additional items which help to ensure safety, and provide convenience for you and your passengers. Perform an annual inventory to keep tools, spare parts, and safety equipment in good condition. Immediately replace any items that have been removed from the kit.

!!! CAUTION

Use only marine grade replacement parts. Most automotive and residential parts are not suitable for use in the harsh marine environment. Using them could lead to premature product failure, property damage, or personal injury.

4.4.1 Capacity Information

On all boats under 26' in length, the manufacturer is required to provide capacity information. For your 235HB, you will find a rectangular decal near the helm. This decal will provide information on horsepower ratings and total capacities which include person capacities, motors, and gear. As an owner you should be aware of the weight on board. Exceeding capacity can endanger your passengers and vessel, as well as void any warranty remaining on the boat should a failure occur. Remember that this is a guideline for normal operation, and does not release you from responsibility should an accident occur. You must use rational judgment when adverse conditions are expected, and reduce your loads to create a margin of safety.

MAXIMUM CAPACITIES

10 PERSONS OR 1850 LBS.

**MAX PERSONS, GEAR, AND MOTOR IS 2682
MAX HP IS 300HP (2X150HP)**

**THIS BOAT COMPLIES WITH THE U.S. COAST GUARD SAFETY
STANDARDS IN EFFECT ON THE DATE OF CERTIFICATION**

Manufacturer:
Model: 235HB

**WORLD CAT
TARBORO, NC 27886 USA**

!!! WARNING

Exceeding capacity or recommended horsepower can endanger your passengers and vessel, as well as voiding any warranty remaining on the boat should failure occur. The maximum horsepower rating for your 235HB is 300 total horsepower.

4.5 Pollution Regulations

The Refuse Act of 1899 prohibits throwing, discharging or depositing any refuse matter of any kind (including trash, garbage, oil and other liquid pollutants) into the waters of the United States. This information is provided in a pamphlet that is normally received when registering your boat. Use the information below as a guideline, but study the pamphlet and understand any local regulations regarding pollution control. As the operator, you are also liable for individuals on your vessel disposing of materials in an improper manner.

4.6 Boating Safety Guidelines

As an owner / operator you should be prepared to handle any situation which arises before departure, while underway, or upon return to dock. Careful planning will add safety and pleasure to your experience and give you the confidence to handle emergencies if they develop. Listed below are some general guidelines which you should follow before any trip:

4.6.1 Pre-Departure

- Establish a float plan and provide it to a person whom you trust. The plan should give the details of your trip, including where you are going and when you expect to return. If you deviate from the plan, notify that person as soon as possible.
- If you anticipate operating in a new area, understand the local rules and request charts or information on any hazards you may not be aware of.
- If you are towing the boat, inspect the trailer including tires, lights, brakes, winch, and overall mechanical appearance.
- Verify that you have all necessary safety equipment. This should include all the USCG required equipment as well as spare parts or other items you decided to include.
- Check fuel levels and determine if you require additional fuel for your trip.
- Examine the weight of the gear on your vessel and make sure you are not overloaded. Distribute the weight evenly on your vessel to ensure predictable performance.

4.6.2 Launching

- Prepare your boat prior to backing down, (i.e. secure all loose items, install garboard drain), then launch your vessel and move away quickly.
- Move your vessel away from the dock and complete a full system check. Ensure that electronics, pumps, and safety equipment are in working order.
- Instruct a passenger on the operation of the boat, and the location and function of all safety equipment onboard. You should never be the only person capable of safely operating your vessel.

4.6.3 Underway (See Chapter 5 on Performance)

- Obey all "Rules of the Road" and any local regulations.
- Never operate a boat under the influence of alcohol or drugs.
- Do not allow individuals under the age of 16 to operate the vessel. Maintain direct supervision of inexperienced operators.
- Ensure that all passengers are safely seated while underway, and are using the hand rails World Cat has provided to remain securely in their seats.
- Use your electronics and judgment to remain abreast of changing weather. Storms develop quickly and you should be prepared to protect your passengers and vessel.
- Maintain a safe speed and respect other boaters as well as those on land. Obey all "No Wake Zones" and be aware of smaller vessels. The wake you produce could endanger other crafts and their passengers.

- Know the limitations of your craft and your experience. Understand the boat's handling characteristics and do not attempt to operate the vessel in conditions that are unsafe or beyond your experience level.

4.6.4 Returning

- Obey navigational markers and be aware of any tidal changes since departure.
- Collect and dispose of refuse properly to maintain our waters for future generations.
- Prepare your boat for loading before moving to the dock. Quickly pull your vessel from the water and move away from the ramp to complete the preparation for trailering.
- Verify that trailer systems are working properly and all items are secured before leaving.
- Wash the boat and perform general maintenance upon returning home. (See instructions in Chapter 5).

As stated above, these are only general guidelines for safe boating. We recommend using these and any other available resources to protect your passengers as well as your vessel. Checklists can be an important tool in accomplishing this.

4.7 Trailering

Due to the nature of the hull, catamarans require specialized trailers. Your dealer will be able to provide them, as well as information on safe trailering practices. Tow vehicles should be rated to handle the load and stresses which accompany trailering your boat. A properly matched trailer should carry 5-10% of the total vessel weight on the tongue. Routine inspections should be performed on the vehicle and trailer prior to each trip, and thorough checks scheduled on an annual basis.

4.8 Anchoring

There are several types of anchors available, each designed to operate in specific bottom conditions. Your dealer can provide information on which styles are most effective in your area.

!!! CAUTION

Never anchor your boat off the stern. The weight at the transom, combined with adverse sea conditions, could allow water to enter the boat over the transom wall.

4.9 Shallow Water

Although your World Cat draws a small amount of water for its size, shallow water should be a concern of all boaters. To avoid this hazard, pay particular attention to navigational markers and know the area you are operating in. Be aware of tidal changes, including those that have occurred during your trip. Rocks, stumps, or other hazards are more prevalent in shallow water and can cause major damage to your hull bottom. Engines can also suffer damage if they are allowed to run in the sand or mud.

If you do become grounded, tilt the motors up to reduce the draft at the transom. Often this will solve the problem; however, it may be necessary to rock the boat from side to side to break the suction along the keel. If you are grounded on an incoming tide, allowing the water to rise can help. Being grounded on an outgoing tide is a larger issue and you need to act quickly to free your boat to avoid being driven further aground. Use the anchor to secure the boat and await the incoming tide, or use it to pull yourself free.

4.10 Emergency Situations

Unfortunately, even the safest boating practices cannot eliminate the potential of emergency situations developing. Therefore, you should prepare yourself and your crew to handle any problems that may arise. Establish specific plans for fires, man overboard, collision, etc., and review them with your passengers prior to departing. Planning allows people to remain calm and gives everyone the confidence to resolve the problem. Below is important information which all owners should be aware of.

4.10.1 Emergency Stop Switch

Lanyard clips are provided on all World Cats and, when used properly, provide an emergency stop for the engines should the driver fall from the helm position, or need to perform an emergency shutdown to respond to or avoid an accident. The clip attaches the driver to the ignition panel using a cord. A pull on the cord will release the clip from the shut-off switch on the panel and shut down the engines. To restart the engines, turn ignition switch to the off position, return binnacle to neutral position, insert safety lanyard back into clip and then turn ignition switches back on. This should only be used to prevent or react to accidents, and the operator is solely responsible for the decision.



4.10.2 Communication

If you witness an emergency or become involved in one, you should request assistance via radio communication or visual signals.

4.10.3 Rendering Assistance

Owners are required by law to render assistance to other boaters involved in an emergency situation such as fire, collision, casualty, etc., as long as it does not endanger your vessel or its passengers.

4.10.4 Reporting Accidents

Federal regulations require that operators involved in an accident file a written account of the situation within 48 hours. Reports should be submitted to the State Boating Law Administrator. You can obtain forms through the USCG or local authorities (i.e. harbor patrol, sheriff or police offices). In the event that a casualty or disappearance occurs as the result of an accident, you must notify the authorities immediately by phone or radio and fill out a written statement.

4.10.5 Weather

Pay attention to weather patterns. If you find yourself in the path of a storm, seek shelter immediately. If you cannot reach a dock, seek refuge inside the boat while the storm advances. Never get in the water and stay clear of metal components on your boat. If lightning strikes, it will likely pass through metal objects seeking a ground.

4.10.6 Towing

Due to an accident or loss of power, it may become necessary to tow another vessel or have your boat towed. If you are providing assistance, never attempt to tow a boat larger than your own. Be certain to use proper lines (ropes) and rational judgment to prevent further damage. Tow lines are under heavy strain, therefore passengers should remain clear of the lines to protect themselves from injury. Use transom eye only for towing. Do NOT use cleats.

4.11 Carbon Monoxide (CO)

!!! DANGER

Carbon Monoxide (CO) is a colorless, odorless, and tasteless gas produced by the exhaust system of any combustible engine. CO can cause brain damage or death if inhaled over an extended period of time. To protect yourself and your passengers, never block the ventilation outlets in cabins, consoles, or other enclosed spaces.

One of the most important considerations when dealing with boating safety is carbon monoxide. Commonly referred to as CO, carbon monoxide is a colorless, odorless, and tasteless gas emitted from any engine exhaust. Including inboards and outboards. A CO particle is close in weight to the air we consume; therefore it does not rise or fall in the atmosphere, but accumulates in enclosed spaces. Boat owners with enclosed heads, cabins, or canvas enclosures should pay particular attention to CO. Be aware that fumes produced on your boat can affect other vessels and other boats can affect you. A primary concern is the use of generators when boats are moored adjacent to each other.

Carbon Monoxide is poisonous and potentially fatal if inhaled over an extended period of time. Symptoms of CO poisoning include:

- Dizziness
- Nausea / Vomiting
- Headache / Throbbing in the temples
- Fatigue
- Muscular twitching
- Inability to focus or think clearly

If you or any of your passengers experience any of these symptoms, leave the area and find a source of fresh air immediately. If your symptoms persist, seek medical attention.


Chapter 5: Performance

5.1 Overview

This chapter will provide information on the performance characteristics of your catamaran; this is not a substitute for seamanship training or hands-on experience. First time boat owners should use the resources detailed in Chapter 1 to learn proper methods of boat operation. Experienced boaters who have never owned a catamaran should study this chapter completely. Do not assume that previous boating experience will apply to all situations, as there are several subtle differences in the handling characteristics of twin-hulled boats. For existing catamaran owners, this chapter should be a reference.

5.1.1 Engine Start/Stop Procedure

Before starting the engines, confirm that the boat is properly fueled, the drain plugs are installed, all required safety equipment is aboard, and passengers and loose gear are safely secured. Turn the 235HB's battery switch to the ON position, verify that both engine control levers are in NEUTRAL, and use the power trim-and-tilt control to lower both engines into the water. Attach the emergency stop-switch lanyard securely to the operator and confirm that its clip is fully seated on the stop switch. At the Yamaha ignition panel, insert the key and turn the ignition switch to the ON position. Then press and release the PORT START/STOP button to start the port engine and the STBD START/STOP button to start the starboard engine. Allow both engines to idle while checking the gauges, warning indicators, steering response, fuel level, cooling-water discharge, and surrounding area. Once both engines are operating normally and all dock lines and fenders are secured, shift into gear at idle speed and move slowly away from the dock. Apply throttle smoothly after reaching open water and adjust engine trim as the boat accelerates onto plane.



NOTICE: Do not operate the engines while they are trimmed completely out of the water. Exact ignition and starting procedures may vary by engine package; refer to the engine manufacturer's owner's manual.

5.2 Motor Trim


The smooth riding characteristics of a catamaran are a result of the twin hull design. Their ability to slice through on-coming waves is far superior to the slamming characteristics seen on conventional vessels. Motor trim plays an integral part in how your catamaran accomplishes this. In a level or bow down attitude, your boat will slice through larger chop, but you may experience sluggish performance, a wetter ride and increased bow steering in a following sea. In a bow up attitude the boat will perform better, but may ride less smoothly. Experiment with the trim settings in various sea conditions to determine what you are most comfortable with. When using the trim to correct a listing condition, imagine an "X" connecting the starboard engine to the port bow, and port engine to the starboard bow (see drawing below).

5.2.1 Bow Up Condition

To correct a bow up condition on the port sponson, adjust the motor trim "down" on the starboard engine. This will help the starboard sponson to rise and level the vessel. If moving to the lowest trim setting on the starboard engine does not correct the list, trim the port engine "up" to assist the change. Reverse the instructions to accommodate for a bow up condition on the starboard sponson.

5.2.2 Bow Down Condition

To correct a bow down condition on the port sponson, adjust the motor trim "up" on the starboard engine. This will help the starboard sponson to fall and level the vessel. If cavitation occurs on the starboard engine, lower it to correct the problem, then trim the port engine "down" to assist the change. Reverse the instructions to accommodate for a bow down condition on the starboard sponson.



5.3 Engine Controls

All factory rigged boats will come equipped with a binnacle control specific to your type of engine. Located at the helm, the binnacle controls the throttle, shift, and trim mechanisms for your engine. Also read the owner's manual provided by your engine manufacturer to determine how to operate the features on your binnacle. If any components of this system need to be replaced, be certain to use the same style and length as the original equipment.



5.4 Steering Controls

Catamarans offer unsurpassed steering control. The wide spacing of the engines, advanced steering components, and handling characteristics of the World Cat hull give operators exceptional maneuverability in even the tightest spaces.

Because of the superior tracking abilities of the World Cat hull, oversteering can present a problem, especially for owners accustomed to operating conventional boats. Conventional vessels have a tendency to lose tracking abilities in rough and following sea conditions, making constant course corrections necessary. However, catamarans do not exhibit those traits and require operators to take a "hands off" approach. To do so, relax your grip and fight the urge to make constant corrections

5.5 Steering Maintenance - Yamaha Digital Electric Steering

This boat is equipped with Yamaha Digital Electric Steering (DES), which is an electronically controlled steering system integrated with the Yamaha Helm Master EX engine control system. Unlike conventional hydraulic steering systems, Yamaha DES does not use a traditional hydraulic helm, hydraulic steering hoses, steering fluid, or a hydraulic tie-bar valve for engine alignment.

To maintain proper steering performance, periodically inspect the steering system for the following:

- Smooth and consistent steering response at the helm
- Proper operation of both engine steering actuators

- No visible damage to steering-related wiring, harnesses, connectors, or engine-mounted steering components
- No Yamaha system warnings or steering-related alerts displayed at the helm or on the engine display
- Proper synchronization and alignment of both engines during operation

If the engines appear misaligned, do not attempt to realign the motors using hydraulic steering procedures. Yamaha DES engine alignment, calibration, and steering system service should be performed according to Yamaha service procedures by an authorized Yamaha technician.

Before operating the boat, always verify that the steering system responds correctly from lock to lock and that both engines move smoothly and consistently. If abnormal steering effort, delayed response, warning messages, or steering faults are observed, discontinue operation and have the system inspected before further use.

NOTICE

If possible, have your dealer or trained marine technician perform routine maintenance or repairs on your steering system. Replace faulty parts immediately.

5.6 Handling Characteristics

World Cat 235HB is a Full Planing hull which provides speed and economy of operation since a limited amount of the hull is in contact with the water. Our proven design provides a superior ride, excellent handling characteristics in a variety of conditions, and speed with economy of operation.

To help you experience *The Ultimate Ride*, study the following sections:

5.6.1 Turning Characteristics

Turning a catamaran is slightly different than cornering on a conventional vessel. Imagine the difference between an automobile and a motorcycle: Automobiles take turns in a flatter, more stable manner similar to a catamaran hull, while motorcycles pitch hard into a turn similar to a monohull. Do not underestimate a catamaran's cornering ability. Hard adjustments to the steering wheel can make a World Cat bite quickly and execute high-performance turns. Experiment with the handling ability of your cat so you are prepared for any situation on the water.

5.6.2 Adverse Sea Conditions

Catamarans are designed to handle some of the roughest waters in the world, but that is no substitute for common sense. As an operator, you are responsible for the safety of your passengers and vessel; therefore, your trips should be limited by your level of experience. Planning and paying constant attention to the weather and sea conditions is paramount. If you are forced to operate in dangerous seas you can be confident that your World Cat, when operated properly, can handle them safely.

Here are a few tips on how to handle your boat in adverse sea conditions:

- When traveling into the wind, changing your direction a few degrees to allow one sponson to settle before the other, can make the ride smoother and allow for increased speed.
- In a rough chop with short wave intervals, increasing your speed may allow the boat to skim across the tops of each wave. This will result in a smoother ride.
- Steer to avoid larger swells and breaking waves.

- In a following sea, position your vessel on the back of a wave and match its speed to remain ahead of the trough. Speed is paramount. Work the throttle to avoid going over the wave or being thrown down the face of a following wave.

5.6.3 Cross-Clutching - Twin Engines

World Cat 235HB twin engines are mounted at a specific distance, based on the configuration of the boat, allowing you to cross-clutch (one motor in forward while one in reverse).

To dock, reverse the boat into a slip: put the outside motor in reverse and turn to face aft. Keeping the wheel straight, steer with the inside motor putting it in forward and reverse to guide you into the slip. Keep it simple and slow.

5.6.4 Get the Boat on Plane

- Trim both engines down (the motors act as trim tabs forcing the bow down).
- Quickly increase speed to get the boat on plane then slow down to 3500 RPM's.
- Adjust trim out until the motors cavitate, then tap trim in.
- Feel / hear the motors and do not watch the trim gauges.
- A smooth ride is more important than having your engine RPM's synchronized.

5.6.5 Keep the Boat Level (if the seas change or people move on the boat)

Trim the **High-Side-High**. When one side of the bow is high compared to the horizon, simply trim the high-side motor up. (If it cavitates then trim the **low-side-low**). Different models have different sensitivity to trim (do not over-correct as this may cause the boat to pitch in flat calm water at high speeds)

5.6.6 Handling Different Sea Conditions

- **Head Sea:** trim motors down (in) to keep the bow down.
- **Following Sea:** trim up (out) to keep the bow out of the water.
- **Calm water:** trim engines up to run on the back of the hull.

5.6.7 Boating Tips

Experience is the best way to determine the handling characteristics of your catamaran. Operating the boat in multiple sea conditions and under various loads will help you predict how the boat will perform in any situation. World Cat provides the following recommendations regarding the performance of your catamaran:

- Establish an RPM chart which details the speed and fuel consumption at various RPM levels to achieve this operation.
- Monitor fuel gauges to determine the amount of operating time remaining at a given reading.
- Determine minimum speed for effective steering in close quarters.
- Determine the turning radius required at various speeds.
- Determine the rates of acceleration and deceleration with various load conditions. Include the distance required to stop the boat at various speeds.

5.7 Performance Factors

Proper setup and maintenance of the systems on your boat is important to ensuring proper performance, but be aware they are not the only factors which affect it. Several things which contribute to the level of performance of your catamaran can change between or during trips.

5.7.1 Engine Efficiency

Without proper maintenance, your engine(s) will gradually lose power, resulting in a loss of speed. Use the recommendations in the engine's owners manual to schedule routine maintenance procedures and as a guide for the correct RPM range for your engines. Neglecting to do so may result in loss of performance and an increased risk of failure.

5.7.2 Propeller Condition

The size and condition of your propeller also plays a major role in the performance of your catamaran. A damaged propeller can result in lower speeds, sudden drops in RPM, increased fuel consumption, and severe vibration while running. Improperly sized propellers can cause damage to your engine as a result of exceeding the maximum or minimum RPM levels.

5.7.3 Weather Conditions

Barometric pressure and humidity can affect the output of your engines. For example, on an extremely hot and humid day, your engine can experience as much as a 10 percent loss in horsepower. Although you should monitor your engines' performance, be aware that the weather could be a major factor in your boat's performance.

5.7.4 Load

Increased load can affect performance, especially if the load is unbalanced. Passengers, gear, and fuel are all examples of things which can affect your vessel. Fuel levels change throughout the day, and greatly affect the attitude of your boat. When necessary, make adjustments to engine trim and load distribution to compensate for fuel usage.

5.7.5 Marine Growth

If you store your boat in the water or fail to clean it after each trip, the existence of marine growth can contribute to a loss of performance. A decline in speed or increased fuel consumption can occur. Prevent this by applying a marine growth inhibitor or by cleaning your boat thoroughly after each trip.

5.7.6 Bottom Paint

Bottom painting your catamaran will also change the performance. Although not significant, you can expect a drop in speed between 1 and 5 miles per hour.

Chapter 6: Systems Information

6.1 Overview

This chapter will provide you with basic information for all the systems on your boat. Understanding this information is imperative, as it directly contributes to the safety and enjoyment of your trips on the water. Talk with your dealer if you need further information on any of these systems.

6.2 Fueling Guidelines

Study the following guidelines thoroughly and consult your dealer if you have questions. Be sure to read the engine manufacturers' recommendations regarding the type and grade of fuel to use for your engines.

!!! WARNING

Avoid methanol or other alcohol-based fuels or additives which can deteriorate fuel hoses. Alcohol-based fuels also absorb water which can lead to engine damage.

!!! DANGER

Follow all safety guidelines while fueling. Leaking or spilled fuel is an explosion hazard. Regular checks of the fuel system are needed to protect you and the vessel.

!!! DANGER

Static electricity can ignite gasoline vapors causing serious injury, death and /or destruction of property.

6.2.1 Before Fueling

- Shut down the engines and turn off all electrical devices including the batteries.
- Close all hatches, port lights, and doors to prevent accumulation of fuel vapors.
- Extinguish cigarettes or other lighted materials.
- Keep a properly charged and correctly rated fire extinguisher nearby.

6.2.2 During Fueling

- Use common sense and obey all safety regulations related to fuel handling.
- Avoid static sparks by maintaining contact between the fuel nozzle and fuel fill.

6.2.3 After Fueling

- Secure the fuel cap and inspect for leaks.
- Clean up any spilled fuel and dispose of the cleaning material accordingly. Do not store fuel-soaked material on your boat.
- Open all hatches, port lights, and doors to allow for ventilation.
- Check for fuel vapors using a "sniff test" and do not turn on electrical devices, including batteries, until you are certain the fumes have dissipated.

6.3 Fuel System

Due to the nature of the hull design, your World Cat 235HB is equipped with separate port and starboard fuel systems. These systems act independently, providing fuel to the engine on their respective side. Tanks are constructed of polyethylene material to prevent corrosion.

Hoses are NMMA certified, and fittings are clamped securely to reduce the potential for leaks. However, comprehensive checks of hoses and fittings should be completed at least annually, including those normally hidden from view. Tighten all connections, replace deteriorated hoses, clamps or fittings, and, if necessary, replace the fuel / water separators during this check. World Cat has provided inspection plates (in the cockpit floor) to assist you with annual maintenance.

If you experience fuel flow problems, remove the fuel feed hose from your engine and connect it to a portable fuel tank. Doing so will help you determine if your fuel system or the engine is the source of the problem. Fuel system repairs and engine maintenance should be performed by a qualified marine technician.

The fuel / water separators are installed between the tank pickup and the engine. They are located in the center aftmost rigging space. Inspect these filters regularly and replace when needed.

6.3.1 Fuel System Benefits

- Automotive-style refueling.
- Automotive Nozzle shut-off for overfill protection – reducing the possibility of accidental fuel spills.
- Fuel nozzle retention.
- Reduces hydrocarbon emission through the use of specially designed fuel fill. The fuel fill has a permanently attached cap incorporating a positive closure mechanism with an audible click, to let you know when the cap is sealed.

6.3.2 Fuel Tank

Your boat is equipped with two low permeation crosslink polyethylene fuel tanks each with a usable fuel capacity of 44.5 gallons. The usable capacity of each fuel tank is different from the tank capacity marked on the tank from the manufacturer. The difference is the accommodation for the unfillable area that has been incorporated into your tank. It is recommended that you follow all of the instructions regarding the filling of fuel tanks.

6.3.3 Fuel Vent

The fuel tank vent is integrated into the fuel fill deck fitting (See fig. 6.3.6) The vent serves as an over pressure / vacuum release with anti-surge and flame / spark arresting protection. The fuel vent system also plays an important role in controlling the "FULL" level of fuel with the use of FLVV (Fill Limit Vent Valve). Grade Valves have been added to the tank which allows proper ventilation of the tank when the boat is stored, or trailered, on a moderate incline, without fuel. Always inspect to ensure that the fuel fill deck fitting is free of debris and in proper working condition.

6.3.4 Fuel Distribution System

The fuel is delivered from the tank to the engine through the “Integrated Fuel Demand Valve” (IFDV), anti-siphon valve, and the fuel line. The IFDV prevents built up pressure inside the tank from being transferred to the engine, while still allowing fuel to flow to the engine for operation. The anti-siphon valve is a safety feature designed to prevent the fuel from siphoning out of the tank if the fuel line were to be cut or broken below the level of the fuel in the tank. Some fuel would still leak from the line, but the valve will not allow the entire contents of the tank to siphon into the boat. (See 6.3.6 and 6.3.7).

What does the IFDV do?

The integrated fuel demand valve, used in conjunction with integrated fuel systems, is for below-deck use, eliminates pressurized fuel from reaching fuel distribution lines / the engine, and ensures that fuel is provided to the engine on demand rather than as a result of pressure in the tank. Additional features include:

- Compatible with Ethanol-blended fuels
- Eliminates the need for rigid fuel distribution lines in pressure relief systems (per ABYC H-24, 15.9)
- 2-year warranty

6.3.5 Filling Fuel Tanks

The fuel system is designed to automatically shut off the fuel nozzle when the tank is full via the “Inlet Control Valve”, (See Fig 6.3.6) similar to an automotive fuel system. The tank is filled when the fuel fill nozzle has shut itself off the second time. Attempting to fill the tank past this point may cause some of the components to not function properly, or malfunction.


!!! WARNING

The use of a portable fuel tank to fill your fuel tanks can result in overfilling and circumvent the safe features designed into our fuel tank system.

!!! WARNING

Modification of any of the fuel system components or the replacement of these components with unauthorized parts may result in over-pressurization of the fuel system and circumvent the safety features designed into your fuel system.

6.3.6 Pressure Relief Fuel System Diagram



6.3.7 Troubleshooting Tips

Possible Failures

Loss of prime on the engine and / or fuel starvation:

- Engine stalls out
- Engine runs lean
- Engine does not draw fuel properly

Find possible leakage points and take corrective action:

- Fuel line leak from tank to engine—replace components as needed
- IFDV O-Ring—replace O-Ring
- Pick-up Tube O-Ring—replace O-Ring
- IFDV— replace IFDV

6.3.8 Integrated Fuel Demand Valve Components



6.4 Ethanol-blended Fuel

Ethanol is an oxygenated hydrocarbon compound that has a high octane rating, therefore it is useful in increasing the octane level of unleaded gasoline.

NOTICE

The use of improper gasoline or additives can damage your fuel system and is considered mis-use of the system. Damage caused by improper gasoline or additives WILL NOT be covered under warranty.

6.4.1 Additives

See your engine owner's manual and your authorized engine dealer for more detailed maintenance instructions.

6.5 Electrical System

The electrical system on your catamaran consists of three major components: the battery system, wiring and circuit protection, and accessories. It is important that you understand the principles of the electrical system so that you can protect the components and troubleshoot any problems you experience.

6.5.1 Battery System

The World Cat 235HB is equipped with two Group 24 batteries. Both Group 24 batteries are dedicated as "cranking batteries", with the stbd side battery also serving house loads.

6.5.2 Battery Distribution

The battery distribution panel consists of a single dual-circuit battery switch with a combine function and an 80 amp push button circuit breaker. The panel is located behind a fold down door on the forward facing center transom seat on the stbd side. The switch controls both batteries.

!!! DANGER

Disconnect the battery cables from the batteries prior to removing or working on the battery management panel. Failure to do so could result in electric shock. Reference the NMMA pamphlet in your Owner's Portfolio for more information.

6.5.3 Emergency Parallel

In the event of a battery failure, the combine function of the battery switch allows you to mechanically link the port cranking battery to the starboard engine or vice versa. It also allows linking between cranking battery and house.

!!! DANGER

All batteries contain an electrolyte, commonly sulfuric acid, which is a caustic and volatile chemical. Use extreme caution when charging or servicing.



6.5.4 24 Hour Circuits

The fuse holders located at the batteries protect the 24 hour essential circuit wiring. Per NMMA and USCG guidelines, these fuses are constantly energized to provide power for bilge pumps and memory functions. This helps to protect your vessel even when you are not available. The battery switch does not need to be "ON" for these fuses to have power. Inspect the fuses regularly. If a fuse blows constantly, have your dealer investigate the problem as soon as possible to prevent damage to your boat.

6.5.5 Fuse/Breaker Locations

24hr Bilge pump fuses- There are inline 7.5-amp fuses connected directly to the batteries. Located in the battery room underneath the center transom seat.

The Main DC 80 amp breaker is located in the battery switch panel.

The Boat fuse blocks are located in the console. See figure 6.5.5 for fuse sizes and location for each circuit.

The Stereo 40 Amp breaker is located in the battery room underneath the center transom seat (Stereo Upgrade Option only).




Figure 6.5.5

6.6 Battery Selection

World Cat supplies the original batteries onboard your vessel. We use 2x Group 24 batteries for cranking with the starboard battery also serving house loads. In the event of a failure, replacements must be of equal size and specifications (see below):

GROUP 24

CCA: 525

MCA: 800

6.6.1 Battery Care

Batteries should be secured in a non-metallic tray and insulated boots should cover the terminals. Depending on the style of battery you choose, inspect the electrolyte and perform routine maintenance as suggested by the manufacturer. Remove corrosion from the terminals quickly to prevent failure. Use a stiff brush and a solution of water and baking soda to remove corrosion, then grease the terminals to prevent further build-up. Be careful to clean up thoroughly to avoid contaminating the electrolyte.

When servicing the batteries, follow the safety procedures shown below and work to avoid electrolyte spills which can harm you and your vessel.

!!! DANGER

All batteries contain an electrolyte, commonly sulfuric acid, which is a caustic and volatile chemical. Use extreme caution when charging or servicing.

6.6.2 Safety

- Use protective clothing and accessories such as aprons, gloves, and eye wear to protect yourself while servicing batteries.
- Avoid cigarettes, open flames, and sparks. Batteries can produce toxic and explosive gases; therefore, store or charge them in a well-ventilated space.
- Keep batteries out of the reach of children and pets.

6.6.3 Exposure

If you are exposed to the electrolyte solution, follow these procedures and seek immediate medical attention.

EXTERNAL - Flush with large amounts of water for contact with the skin. If severe irritation occurs or it contacts your eyes. Seek medical attention immediately.

INTERNAL - Consume large amounts of water or milk, coupled with milk of magnesia, a beaten egg, or vegetable oil. Seek medical attention immediately.

The guidelines above are basic and do not alleviate the owner of responsibility should an accident occur. Use good judgment and common sense to avoid an accident.

!!! CAUTION

When reconnecting your batteries, always connect the red cable to the positive terminal and the black cable to the negative terminal (in that order). Reversing them can damage your electrical system and create the potential for electric shock.

!!! CAUTION

Never disconnect a battery while underway. Doing so may result in damage to your boat's electrical system and the engine's alternator.

6.7 Wiring and Circuit Protection

Your World Cat is wired using marine grade tin coated copper wire instead of standard copper wire. Tin coated copper is manufactured to withstand the harsh saltwater environment better than standard copper, which is used for residential applications. Environmentally sealed Deutsch™ connectors are installed on all accessories located below the waterline to ensure watertight connections. The remaining devices are installed with high quality splices and terminals, which are heat shrunk to protect the integrity of the connection. Harnesses are routed through PVC rigging tubes to prevent chafing and covered with sheathing when necessary.

6.8 Control System

Your World Cat is equipped with a traditional switch operated DC control system. Accessories not integrated into the control unit can include lights with integrated switches, marine head controls, stereos, aftermarket electronics and 12V outlets. These devices draw current from the accessory fuse blocks. The fuse blocks are similar to those found in automobiles and use ATC blade style fuses to protect a circuit. You can obtain replacements for these fuses from your dealer or local auto parts store. Always replace a damaged fuse with one of equal rating.

!!! CAUTION

When working on your electrical system, disconnect the batteries to prevent shock, or damage to your electrical system. If possible, have an electrician perform repairs.

!!! CAUTION

Failing to use the correct replacement breaker could result in failure of the device or damage to the electrical system. Contact your dealer for repair information.

Ground blocks are another integral part of your electrical system. These are connected to the common battery ground and individual appliances to provide a path for current flow back to batteries.

For customers unfamiliar with electrical systems, World Cat recommends the following book:

Boating Magazine's: Powerboater's Guide to Electrical Systems


Written by: Ed Sherman

Publisher: International Marine (Division of McGraw Hill Companies)

Copyright: 2007 International Marine


6.9 Dash Switch Panel

The dash switch panel controls the lights, pumps, and other electrical accessories on your 235HB. It is located near the center of the dash above the binnacle. The panel features illuminated push-button switches to help identify system status. When the navigational lights are turned on, the "NAV/ANCHOR LIGHTS" switch backlighting illuminates green. When this switch is active, all other switches are illuminated blue. When an individual accessory is activated, the corresponding switch illuminates red. A second press on the "NAV/ANCHOR LIGHTS" switch will illuminate the switch red and returns all other switch backlights off. The horn switch is always illuminated blue and illuminates red only while the switch is being pressed.



6.10 Hardtop Switch Panel

The hardtop switch panel controls the overhead helm light as well as the aft-facing spreader light. Both switches have their dedicated circuit breaker beside the switches. This panel is excluded from your boat if you have chosen the hardtop-delete package.



6.11 Accessories

Electrical accessories include all lights, pumps, and gauges assembled into your World Cat. Certain accessories are standard to each model, while others are optional equipment. Below is a list of accessories and their function.

6.11.1 Navigational Lights

Per USCG guidelines, all powered vessels must have navigational and anchor lights. Your World Cat is equipped with navigational lights at the bow and an anchor light on your hardtop. These lights must be used in accordance with USCG regulations when anchored or underway.

If you have selected the hardtop-delete package for your boat, the anchor light is located on the stbd aft gunnel.

6.11.2 Courtesy Lights

Cockpit lights are located at floor level to provide light while operating in low light conditions.

6.11.3 Hardtop Lights

Hardtop Lights include a down-facing courtesy light overhead of the helm, and an aft-facing spreader light.

6.11.4 Livewell Lights

Livewell Lights are located in both the stbd and port aft tubs. The port side is a red light, and the stbd side is a white light.

6.11.5 Bilge Pump / Float Switch

Your World Cat is equipped with two 1100 GPH bilge pumps located aft: one on the port side and one on the starboard side. They can be accessed through the motorwell hatches. Bilge pumps evacuate standing water in the bilge. They can be operated manually, or automatically by the float switch. The float switches are connected to the fuses at the batteries.

Inspect the operation of your bilge pumps and their connections at least annually. To do so, activate the pump by momentarily lifting the arm on the float switch, then check the operation using the manual switch at the dash. When testing, do not allow the pumps to run dry for more than two to three seconds. Extended dry operation can result in damage to your pump. Keeping your bilge areas clean can also help extend the life of your pump.

6.11.6 Seacocks

The Ball Valve (seacock) is installed on the water intake for the raw water system. The seacock must be in the open position for the system to work. When open, the handle will be parallel to the valve. In the closed position the handle is perpendicular to the valve (see picture below). World Cat recommends that the seacock remain in the closed position when not in use, or when the boat is left unattended to prevent the vessel from taking on water due to a plumbing failure.



OPEN



CLOSED



6.11.7 Raw Water Pump

Supplies pressure to the raw water system. Contains a pressure switch similar to a residential well pump. You can leave this appliance on at all times while underway. The raw water pump and strainer are accessed through the port side motorwell hatch. The strainer is connected to a high-speed pickup through the seacock located on the inboard side of the port sponson. The seacock must be open for the system to work. World Cat recommends that the seacock remain in the closed position when not in use, or when the boat is left unattended to prevent the vessel from taking on water due to a plumbing failure.



6.11.8 USB Outlet

Located at the helm on the dash, this outlet provides power to aftermarket accessories such as cell phones, electric reels, and spotlights. The outlet is independently wired to the fuse panel.

6.11.9 Horn

This functions identically to the horn found on a passenger automobile and is operated by the switch labeled "Horn" on the dash switch panel.

6.11.10 VHF System

The ICOM M330G VHF radio provides reliable marine communication for routine vessel-to-vessel contact, marina communications, and emergency use. The system includes a dedicated 4-foot Shakespeare VHF antenna on your hardtop to support clear transmission and reception while underway. The radio is equipped with Digital Selective Calling (DSC) and integrated GPS capabilities, allowing compatible distress and position information to be transmitted when the radio is properly registered and configured. Operators should monitor the




appropriate channels, follow all applicable communication regulations, and become familiar with emergency calling procedures before operating the boat. For specific setup and operating instructions, refer to the ICOM M330G owner's manual.

If you have selected the hardtop-delete package for your boat, the VHF is located on the port side of the console.

6.11.11 Fusion Apollo MS-RA670 Marine Stereo

The Fusion Apollo MS-RA670 marine stereo provides AM/FM radio, Bluetooth audio streaming, USB media playback, and support for compatible connected audio sources. The unit includes Fusion digital signal processing for improved sound quality and allows control of multiple audio zones from the stereo interface. When connected to the vessel network, the stereo can also integrate with compatible Garmin displays and Fusion PartyBus systems for convenient audio control throughout the boat. For specific operating instructions, refer to your Fusion Apollo MS-RA670 owner's manual.



6.11.12 Plumbing System

The intake and discharge of water is integral to several of the features and accessories provided on your boat, including sanitation devices and water systems. World Cat installs the plumbing components for these systems using high quality marine hoses and stainless clamps. However, this does not eliminate the need for routine checks of plumbing components or connections. A failure resulting from a deteriorated hose or connection could cause your boat to take on water or become swamped. For additional information about the plumbing system refer to section 10.2 on page 48 and speak with your dealer.

6.11.13 Livewell and Livewell Pump

The port livewell on your 235HB has a capacity of 20 gallons. It is equipped with a dual purpose livewell pump and adjustable flow regulator. The pump is located in the port bilge area, accessible via the port motorwell hatch, and can be activated by a toggle switch on the dash switch panel. The wiring is secured to the pump using a tie-strap and must be disconnected prior to removing the pump.

The livewell pump draws water through the high-speed pickup mounted on the inboard side of the port sponson. A seacock is installed between the pickup and the pump to allow you to seal the system between use, or in the event of a plumbing failure. To operate the livewell, first verify that the seacock and flow regulator are open, then install the drain plug in the bottom of the tub. When you have completed these steps, engage the livewell pump using the switch at the dash. Water will fill the tank until it is level with the overboard drain, which evacuates water through the transom. To clear bait residue from the tank during operation, temporarily remove the drain plug. When you have finished using the livewell, remove the drain plug to allow the water to drain overboard.



NOTICE

While underway, leaving your livewell seacock open could result in inadvertently filling your livewell. To prevent this, close the seacock when the pump is not in operation.

NOTICE

Operating the engines in reverse can cause excessive ventilation near the livewell intake, causing the pump to airlock. To prevent this, turn the pumps "OFF" prior to any continuous or high speed reverse operation. If your pump does become air locked, turn the pump "OFF" for 15 to 30 seconds to correct the problem.

6.11.14 Fishbox and Fishbox Pumps

The in-floor port and stbd insulated fishboxes (170-quart each) are equipped with dedicated fishbox pump-out systems to help remove water, ice melt, and fishbox waste from the boat. There are two fishbox pumps, one serving the port in-floor fishbox and one serving the starboard in-floor fishbox. The pumps are located in the port and starboard mechanical spaces, directly beneath the insulated livewell tubs.

Each fishbox pump is operated from the dash switch panel, with separate switches provided for the port and starboard fishbox pumps. When activated, the pump draws from the fishbox drain and discharges the contents overboard through the applicable thru-hull fitting. After use, rinse the fishboxes with clean water and run the pumps only long enough to clear the remaining water. Turn the fishbox pump switches off when the fishboxes are drained.



6.11.15 Fresh Water and Fresh Water Pump (Option)

The optional freshwater system is supplied by a 10-gallon freshwater tank and freshwater pump, both located inside the console. The tank is filled through the freshwater fill port located on the port side of the console unit. To operate the system, ensure the tank has water, then turn on the freshwater pump using the switch on the dash switch panel. The pump supplies water to the cold freshwater pull-out shower located in the port aft section of the transom area. Turn the freshwater pump switch off when the system is not in use.



Chapter 7: Maintenance and Service

7.1 Overview

This chapter provides basic information for maintaining the original appearance and dependable performance of your World Cat. Although your vessel is constructed of the finest materials available, the harsh saltwater environment and other factors, including geography and usage rate, will affect its finish and function over time. It is imperative that you understand how to care for your catamaran properly. Some simple steps will help maintain its aesthetics, value, and reliability.

7.2 Gelcoat Maintenance

Gelcoat is a thin layer of resin mixed with colored pigments, which provides the exterior finish on your boat. Gelcoat provides a smooth durable surface to protect the fiberglass construction of the hull, but is still flexible enough to absorb the pressure exerted upon it during operation. Mainly used for cosmetics, gelcoat is relatively simple to maintain. However, without routine cleaning, it will discolor due to the microscopic pores in the surface.

7.2.1 Cleaning

After each trip on the water, or after trailering long distances, you should clean the boat immediately. Washing the boat with mild detergents, such as dishwashing soaps, and fresh water will help eliminate build up or discoloration resulting from environmental pollutants. Use a sponge or other soft cleaning device on the smooth exterior surfaces of the hull and deck. A soft brush can be used when cleaning nonskid portions of the deck. Make sure to rinse the boat thoroughly after cleaning.

!!! CAUTION

Using strong or caustic cleaning agents, such as bleach, citrus based cleaners, or one containing ammonia, will damage the appearance and strength of your gelcoat.

7.2.2 Waxing

Similar to automotive finishes, gelcoat will begin to fade over an extended period of time. Constant exposure to environmental pollutants will result in a loss of shine. However, it is possible to restore the original luster and color using a polishing compound (mild abrasive) or a rubbing compound (harsh abrasive). Each will remove scratches, discoloration, and help restore weathered gelcoat surfaces. You should select which compound to use based on the severity of the problem

Use the following steps to restore the finish of your gelcoat.

Note that these procedures assume a moderate level of expertise of the person performing the work. If there is any doubt about ability to successfully accomplish the procedure, for best results it may be best to turn the process over to a professional.

- Clean the affected area completely using a mild detergent.
- Gently wet sand the affected area using a fine sandpaper (600 grit) to remove any stains. Use plenty of water and always sand in one direction using curved strokes. Sanding in alternating directions could result in damage to the finish.
- Apply polishing compound to a buffing pad and follow the manufacturer's instructions. If you apply the compound mechanically, we recommend a lamb wool buffing pad and an electric buffer capable

of 1750 to 1800 RPM.

- When you have completely buffed the area, wash away any remaining compound using clean water.
- After thoroughly cleaning the surface, wax the affected area. This will help restore the finish and provide a seal against future discoloration.

!!! CAUTION

Using strong or caustic cleaning agents, such as bleach, citrus based cleaners, or one containing ammonia, will damage the appearance and strength of your gelcoat.

!!! CAUTION

When using an electric buffer, maintain constant motion. Allowing the pad to rest on an isolated spot can cause heat buildup, which can damage the gelcoat.

!!! CAUTION

Routinely clean and wax your catamaran to help prevent the need for excessive use of rubbing and polishing compounds, which over time can deteriorate the gelcoat.

By following the instructions listed above you can guarantee that your catamaran will remain in near showroom condition and remain a source of pride for years to come.

7.2.3 Repair

Although gelcoat is a flexible material capable of handling environmental punishment and extended use, it is susceptible to scratches, blistering, and cracking over time. Gelcoat distortion or cracking is unappealing, but rarely represents any structural failure. Have your dealer inspect any damage to your gelcoat to determine the nature of the failure. If it is only cosmetic, they can provide color matched kits, instructions, and any chemicals you need for application or cleanup. Structural damage should be repaired by your dealer or a qualified fiberglass repair shop.

!!! WARNING

Gelcoat and the chemicals used for its application and cleanup are extremely flammable and toxic. Follow all handling and mixing instructions, provide for proper ventilation, and keep water containers nearby to submerge catalyzed materials.

7.3 Bottom Paint

If you intend to leave your boat in wet storage, or routinely dock it for more than a few days, you should coat the hull beneath the water line with anti-fouling paint. This will help prevent marine growth, such as barnacles, which damage the gelcoat and affect performance. World Cat recommends using an epoxy barrier coat prior to painting a new vessel. This will help to prevent, but will not eliminate, gelcoat blistering on the hull, which is not covered by the warranty. Your dealer can provide information on bottom painting to protect against environmental toxins in your area. Anti-fouling paints are made to dissolve over time, so inspect and clean the hull bottom annually and recoat when necessary.

7.4 Upholstery

Basic Stains - Clean with a mild detergent and a soft to medium brush, or an all-purpose cleaner and rinse well with fresh water after cleaning.

Mildew - Use a 4 to 1 mixture of water and ammonia, brushing the stain vigorously to remove the bacteria responsible for the mildew. If the stain remains, briefly apply bleach to the area and rinse with fresh water.

Tough Stains or Mildew - Use a mixture of 1 tablespoon of ammonia, 1/4 cup of hydrogen peroxide, and 3/4 cup distilled water. Briefly, apply to the surface, allowing the peroxide to bubble. Rinse with fresh water.

!!! WARNING

Do not mix ammonia and household bleach. Doing so will result in the formation of deadly chlorine gas. If it is necessary to use bleach, clean up any traces of ammonia and ventilate the work space for a minimum of 15 minutes prior to applying bleach.

7.5 Trim / Plexiglass / Polyethylene

World Cat uses vinyl, plexiglass, and polyethylene material (Starboard™) throughout the interior of our catamarans.

Use the following instructions to care for these items:

- Use mild detergents to clean vinyl trim commonly used in cabins and helm. Routinely use a commercially available surface protector to seal the vinyl.
- Starboard™ can be cleaned using surface cleaners such as 409™.

7.6 Stainless Steel / Aluminum

Stainless steel and aluminum are used throughout your vessel. World Cat uses only 316 marine grade stainless hardware and anodized aluminum to provide you with years of service; however, these metals can deteriorate and fail if improperly cared for. Upon returning, clean all hardware using a mild detergent and rinse thoroughly with fresh water. Avoid using abrasive cleaners or chlorine based products, as they will remove the metal's protective coating and lead to pitting or rust. Throughout the year, coat the metal using a non-abrasive metal protector to help displace moisture, remove contaminants, and shield the metal. World Cat recommends high quality sealants such as Boeshield T-9™ developed by Boeing™ Aviation. If you cannot find it locally call PMS Products Inc. at 800-962-1732.

7.7 Bilge Compartments

Routinely check the condition of the bilge compartments in your boat. This will help identify potential problems and eliminate odors associated with stagnant water and the buildup of residue. Clean the compartments using a freshwater rinse. This will also enable you to check the function of your drain system and the operation of the bilge pumps.

7.8 Cockpit Drains

All World Cats have four drains located in the cockpit, two on both the starboard and port sides. These drains are designed to quickly evacuate the cockpit should the boat become swamped. Flushing these drains routinely will ensure the safety of your crew and vessel, as well as eliminate the potential for odors associated with fish residue. These drains are evacuated through the scuppers located on the hull side. Each scupper has a rubber flap to prevent water from entering the boat. Check this material occasionally to keep the scuppers free of debris and in good working condition.

7.9 Winterization

Routine maintenance checks should be performed prior to each trip in accordance with Chapter 1, but a broader assessment should be done before winterizing your catamaran and prior to the first trip of the season. If your local climate does not require winter storage, complete the following steps at least annually to ensure the safe operation of your boat.

- Do not leave loose items or personal effects onboard during storage. Remove all trash and debris prior to cleaning the boat.
- Before storage, clean the boat thoroughly, including exterior surfaces, fish boxes, livewells, and thru hull fittings. If possible, leave lids open slightly to allow fresh air exchange.
- Remove the garboard drains and store the boat with the bow up to allow drainage.
- Inspect all electrical connections and the operation of pumps or other electrical devices.
- Perform repairs if necessary. Coat electrical panels with an anti-corrosive spray (available from your dealer.)
- Inspect the batteries and charge fully to prevent damage during storage.
- Disconnect the cables and apply a coat of grease to the terminals to prohibit corrosion.
- Inspect all plumbing components and connections to prevent leaks.
- Replace any damaged hoses.
- Drain all lines and devices to prevent damage from freezing.
- Lubricate valves to maintain proper operation.
- Use the manufacturer's recommendations for portable and marine heads.
- Inspect fuel system components and replace fuel / water separators. You can keep the system fueled but do not overfill, and use a fuel additive to prevent condensation.
- Lubricate hinges and coat all metal surfaces with a metal protecting compound. Tighten down any hardware if necessary.
- Inspect caulking around hardware, windows, hatches, etc., to prevent water damage. Normal use will break down sealants and can lead to costly repairs if not maintained.
- Remove or cover all electrical devices to prevent damage from UV rays. The rays will cloud electrical displays and make them hard to read.
- Remove cushions and store indoors to prevent damage.
- Winterize the engines and controls per manufacturer's recommendations and inspect all connections, filters, and parts thoroughly. Replace parts as needed.

7.10 Maintenance Schedule

Maintenance	Each Use	Weekly	Monthly	Quarterly	Yearly	As Needed
Clean hull below the waterline				X		X
Bottom paint the hull					X	X
Check / replace sacrificial anodes			X			
Wash boat hardware and canvas	X		X			
Wax exterior gelcoat				X		X
Clean & protect hardware						X
Clean exterior upholstery	X					X
Clean cabin & interior upholstery						X
Flush engines with fresh water	X					
Spray metal components in bilges			X			
Clean bilge				X		X
Check bilge for leaks	X		X			
Inspect steering & controls	X					
Inspect fuel systems for leaks	X					
Replace fuel filters					X	X
Lubricate fuel fill o-rings			X			
Inspect fire extinguisher			X			
Test bilge pump auto switches	X		X			
Check battery electrolyte & service			X			
Check proper functioning of pumps	X					
Replace pumps					X	X
Replace gaskets						X
Inspect & operate thru-hull valves			X			

7.11 Maintenance Log

[illegible]

Chapter 8: Hurricane Preparedness

Customer Checklist

Equipment To Be Kept Onboard

- ☐ Chafing Gear
- ☐ Fenders
- ☐ Flashlight with spare batteries
- ☐ Two sufficient anchors with 300' or more oversized rode

Battery-operated radio Check Monthly:

- ☐ Exterior lights operable
- ☐ Auto bilge pump operating (check battery)
- ☐ Hatches are watertight
- ☐ Power and electric gear operating
- ☐ Engine battery charged
- ☐ Flashlight battery charged
- ☐ Radio batteries charged

To Do At A New Marina:

- ☐ Learn marina approaches and basin.
- ☐ Learn the size and type of your mooring.
- ☐ Ensure mooring and lines are sufficient for all likely wind direction and velocity.
- ☐ Ensure mooring has enough weight and scope and is properly set.
- ☐ Learn your moorage lease and rental agreement responsibilities.
- ☐ Learn responsibilities for your boat's safety when a hurricane is approaching.
- ☐ Develop a plan for securing your vessel outside the marina if you plan to evacuate.
- ☐ If evacuating, visit the site by boat and time the trip.
- ☐ Learn what possible delays you may encounter when evacuating (drawbridges, boat traffic ,etc.).
- ☐ Photograph your boat and surroundings.
- ☐ Keep a list of all equipment on board.
- ☐ Keep a list of all equipment that will be removed during storm preparations.
- ☐ Keep a complete set of records for your boat at home.
- ☐ Give the marina operator the name and number of your absentee skipper.
- ☐ Give the marina operator a description of your boat, registration number and location.

Docked Boat Preparations:

- ☐ Strip all removable items, including spare rigging.
- ☐ Clear self-bailing cockpit drains.
- ☐ Close all thru-hull fittings.
- ☐ Set chafing gear where lines will rub (chocks, cross lines, deck edge, dock edge etc.).
- ☐ Remove portable fuel and oil storage containers.
- ☐ Remove ship papers.
- ☐ Shut off fuel tanks.
- ☐ Leave anchor light on.
- ☐ Leave auto bilge pump on.
- ☐ Check openings to ensure boat is watertight.

- ☐ Set and check storm anchors.
- ☐ Consider attaching 3 sets of bow and stern spring lines.
- ☐ Consider attaching lines to cleats at a 45 degree angle.
- ☐ Consider tying your boat between two piers or along a pier and anchored off one side.

Moored Boat Preparations:

Make Plans To Have Someone Pick You Up From Your Boat Before The Storm Arrives

- ☐ Strip all removable items, including spare rigging.
- ☐ Clear self-bailing cockpit drains.
- ☐ Close all through hull fittings.
- ☐ Remove portable fuel and oil storage containers.
- ☐ Remove ship papers.
- ☐ Shut off fuel tanks.
- ☐ Leave anchor light on.
- ☐ Leave auto bilge pump on.
- ☐ Check openings to ensure boat is watertight.
- ☐ Use storm pennants to increase scope.
- ☐ Attach chains directly to pennants instead of swivels.
- ☐ Add an emergency catenary weight at the vessel end of the chain.
- ☐ Use double or triple chafe protection.
- ☐ Use chafing gear over entire length of pennants.
- ☐ Use two pennants.
- ☐ If no permanent mooring is available, use two storm anchors at 45-degree angles.

Trailerable Boat Preparations

Store in a garage:

- ☐ Strip all removable items, including spare rigging.
- ☐ Clear self-bailing cockpit drains.
- ☐ Close all through-hull fittings.
- ☐ Remove portable fuel and oil storage containers.
- ☐ Remove ship papers.
- ☐ Shut off fuel tanks.
- ☐ Leave auto bilge pump on.
- ☐ Check openings to ensure boat is watertight.
- ☐ _____
- ☐ _____
- ☐ _____

If no garage is available:

- ☐ Secure trailer to a sturdy object.
- ☐ Let half the air out of the trailer tires.
- ☐ Put wood blocks between the frame and axle.
- ☐ Take out the drain plugs.
- ☐ Cover with tarp.
- ☐ Use tie-downs.
- ☐ _____
- ☐ _____
- ☐ _____

Anchored Boat Preparations

Make Plans To Have Someone Pick You Up From Your Boat Before The Storm Arrives

- ☐ Strip all removable items, including spare rigging.
- ☐ Clear self-bailing cockpit drains.
- ☐ Close all through-hull fittings.
- ☐ Remove portable fuel and oil storage containers.
- ☐ Remove ship papers.
- ☐ Shut off fuel tanks.
- ☐ Leave auto bilge pump on.
- ☐ Check openings to ensure boat is watertight.
- ☐ Use 3 or 4 substantial anchors and good tie rope.
- ☐ Tie your boat high on the mainland to a substantial tree or similar structure.
- ☐ Do not tie parallel to the bank.
- ☐ Keep a navigable passage at your stern to allow other boats passage.
- ☐ Use enough line to allow for storm surge.
- ☐ Leave enough room between your boat and others to allow for swing.
- ☐ Take valuables off.
- ☐ _____
- ☐ _____
- ☐ _____
- ☐ _____



LIMITED WARRANTY

2027 MODEL YEAR LIMITED WARRANTY

Congratulations on the purchase of your World Cat™ product. We want you to have years of pleasure and fun aboard your new World Cat boat. This document is your Limited Warranty. It describes the terms and conditions of the warranty agreement between us. It applies to all World Cat Products sold under the World Cat or brands manufactured beginning with the 2027 Model Year. Your Model Year is identified by the Hull Identification Number ("HIN"), which is unique to every boat and is located on the stern.

It is important to understand what a limited warranty does. It is an agreement between you and World Cat that your vessel will be free from substantial defects in material and workmanship for a specified length of time. However, if a defect does occur, you and World Cat agree that you will allow World Cat to repair it or, at our discretion, replace it as set forth herein. All products need repairs and maintenance from time to time, especially boats. Boats have a rough life in that they often go long periods between use, and when they are used, boats must perform in a difficult environment. Because of this, you should understand what your limited warranty does and does not cover and the terms and conditions that apply to it. Please note that there are disclaimers and limitations on page two of this Limited Warranty.

I. LIMITED WARRANTY

1. **Ten Year Limited Hull Warranty.** World Cat warrants that it will repair, or at its sole and exclusive discretion, replace any substantial defect in material or workmanship in the hull (defined as the one-piece fiberglass molded part that acts as the vessel's running surfaces) for the first ten (10) years following the date of purchase by the original retail owner. In the event that World Cat determines that your hull must be replaced, you agree to give us back the original hull and we will put a new hull on your boat. The replacement hull will be an upgraded model if the original model is no longer offered. Transfer of all accessories, including engines and electronics, will be at owner's expense.
2. **One Year Limited Material and Workmanship Warranty.** World Cat warrants that it will repair or, at its sole and exclusive discretion, replace any substantial defect in material or workmanship in any other parts or components of the boat that do not carry their own, separate written warranty, for a period of one (1) year following the date of purchase by the original retail owner. Under no circumstances will World Cat warrant the engine, trailer, or electronics.

II. WARRANTY LIMITATIONS

This Limited Warranty does NOT cover the following:

1. Defects and/or damage arising out of engines transmissions, running gear and outdrives, metal plating or finishes, windshield breakage, and leakage due to seal and/or caulk shrinkage and/or normal wear and tear.
2. Defects and/or damage to gel coat or painted surfaces including, but not limited to, discoloration, fading, chalking, and/or osmotic blistering.
3. Defects and/or damages related to accessories, alterations, modifications, or installations which were not part of the boat when shipped from the World Cat factory, and/or not authorized in writing by World Cat.
4. Damage and/or defects related to misuse, such as groundings and impacts with docks, pilings, navigation buoys, etc.; accidents; reckless, unsafe, or improper use relative to existing sea conditions; lack of recommended maintenance, or improper trailering, blocking or lifting; and/or



LIMITED WARRANTY

repairs by the owner or other persons without prior, written authorization from World Cat.

5. Use of the boat for competition, racing, or used for rental, business, or commercial purposes without the prior written authorization of World Cat. Rental, racing, business, or commercial use without prior, written authorization voids this warranty.
6. Defects and/or damage related to operation of the boat in violation of any Coast Guard regulations or other governmental laws, rules, or regulations.
7. Mildew, water damage, dry rot, staining or water absorption on interior materials and/or surfaces including but not limited to upholstery, cushions, cabinets, or floor coverings, as a result of sustained exposure to humid conditions.
8. Galvanization and/or electrolysis or and other damage caused or contributed to by stray electrical current.
9. Defects, injury, costs, or damages arising out the use of engines with a rated horsepower exceeding the maximum rated horsepower for each model as defined by World Cat Boats or as reflected on the capacity label.

III. CUSTOMER OBLIGATIONS

1. You must sign and submit to World Cat the "LIMITED WARRANTY REGISTRATION FORM" within thirty (30) days of the date of delivery. Your dealer can do this for you, but it is up to you to request them to do so. THE REGISTRATION FORM IS NOT A WARRANTY AND MAY NOT BE USED TO MODIFY OR CONFLICT WITH ANY TERMS OF THIS LIMITED WARRANTY.
2. In the event you discover a defect, you must first notify the dealer from whom the boat was purchased within a reasonable period of time (not to exceed thirty (30) days) after you know or should know the defect exists.
3. World Cat will not be responsible for damage or to continue to repair or replace your boat or any part of it if your continued use prior to repair causes additional damage.
4. If you believe a claim has been denied in error or the dealer has performed the warranty repairs in an unsatisfactory manner, the owner must notify the World Cat Customer Service Department in writing within thirty (30) days of the repair attempt at the address listed below under "Notice." World Cat will then review your claim and take appropriate follow-up action.
5. You should keep records of all maintenance services. This record of proper maintenance may be required to determine warranty coverage on certain repairs and should be transferred to each subsequent owner. Please refer to the Owner's Manual that came with your boat for the proper maintenance procedures.
6. In the event a repair must be made at a factory authorized repair center or at the World Cat factory, transportation to and from the repair center shall be made at the Customer's expense and not at the expense of World Cat or its authorized dealer.

IV. TRANSFERABILITY

You can transfer the unexpired term of this limited warranty once to a new owner, provided that the transfer occurs during the first (5) five years after the date of purchase. A copy of the bill of sale from the original owner is required, as well as completion of the transfer form. The new owner must register the transfer of limited warranty within 30 days of purchase, by sending a written request to the address listed in the Notice section below along with a registration fee of \$395. World Cat reserves the right to reject any warranty transfer request for a boat that has been damaged, neglected or otherwise previously excluded from warranty coverage.



LIMITED WARRANTY

V. DISPUTE & RESOLUTION

Mandatory Mediation before Suit

In the unlikely event we cannot agree on a resolution of any issue regarding your boat and/or the terms of this agreement, or in fact of any issue arising between you and World Cat and/or a World Cat dealer, you and World Cat agree to submit the dispute to mediation. Mediation is a settlement conference before a trained mediator that you and a World Cat representative with authority to resolve our differences are required to attend. We will pay the costs of mediation, but World Cat will not be responsible for travel expenses, other costs, or attorney fees. You and World Cat will select a mutually agreeable mediator together. If we cannot agree, then any judge with potential jurisdiction over the case will select the mediator. The mediation will be at a mutually agreeable location, but it will also be within 100 miles of the place of purchase unless otherwise agreed. You agree that no lawsuit or arbitration or administrative action of any kind for any type of damage or remedy may be requested or filed until this mediation is completed. The mediation shall be completed within six months of the first demand by you or World Cat to mediate unless otherwise agreed.

VI. DISCLAIMER OF IMPLIED WARRANTIES

This is a limited warranty. World Cat makes no warranty, other than as contained herein and no decals, promotional literature, brochures, website materials and/or pre-delivery service inspection records/forms or brochures shall be construed as any additional or separate warranty. To the extent allowed by law, all warranties of merchantability, workmanship, seaworthiness, or fitness for a particular purpose are disclaimed and excluded.

VII. LIMITATION OF REMEDY AND EXCLUSION OF CERTAIN DAMAGES

All incidental and/or consequential damages are excluded from this limited warranty. You and World Cat agree that your sole and exclusive remedy under this limited warranty (and any implied or statutory warranty) is the repair or replacement of the vessel or defective component as set forth above. No other legal or equitable remedies shall be available to you in return for the benefits of this limited warranty.

VIII. PERFECT TENDER

A "perfect tender" means that we have a right to replace your boat if, in our discretion, the claimed defect requires replacement, and we agree to do so immediately. For these purposes, "immediately" means within ninety (90) days from the date you first notify us that you believe that we have failed to honor this limited (or any other) warranty and/ or otherwise failed to properly remedy a substantial defect. In the event you notify us in writing, per this agreement, of a failure on our part and we agree to replace your boat with a new boat as described in your original purchase agreement, then in the event you reject the offer of a new boat and file a lawsuit or other legal claim, you agree that in return, World Cat will be not responsible for your attorney fees and court costs. If you have financed the boat, you must either pay off the amount you owe before we deliver the new boat, or we will assist you to substitute the new boat as collateral. We are not responsible for paying off your present boat.

IX. OTHER TERMS AND CONDITIONS

This limited warranty gives you specific legal rights, and you may also have other rights, which may vary from state to state. Some states and/or federal laws do not allow limitations to implied warranties or as to remedies or certain damages, so the above disclaimers and/or limitations may not apply to you.



LIMITED WARRANTY

World Cat will discharge its obligations under this warranty as quickly as possible, but we cannot guarantee any specific completion date. This is due to the potential complexity of the repair or the availability of parts from sources over which World Cat has limited control. You agree that the time for repairs does not include time spent waiting for parts or the time your boat may end up stored at our factory or at a dealer for your convenience or due to scheduling. World Cat reserves the right to change or improve the design of its boats, without obligation to modify any boat previously manufactured. World Cat shall in no way be responsible for any repairs not PRE-AUTHORIZED by a World Cat Customer Service Manager or repairs performed by a repair shop not PRE-AUTHORIZED by a World Cat Customer Service Manager. "PRE-AUTHORIZED" means that we have prior approval in how the repairs are performed before they are performed.

X. NO WAIVER OF THESE TERMS

The terms, conditions, limitations, and disclaimers contained herein cannot be waived except by a management level employee of World Cat. Any waiver we give shall be in writing. Neither the dealer, nor any service, sales and/ or warranty representative of World Cat are authorized to waive and/or modify these conditions, limitations and/or disclaimers.

XI. NOTICE

All communications and notices from you and/or a new owner requesting a transfer of this limited warranty should be sent to: World Cat Customer Service, 1090 West Saint James Street, Tarboro, NC 27886 or faxed to 919-882-8035. You can also email us at: service@worldcat.com, but you must request an acknowledgment that our Customer Service Department actually received it.

ACKNOWLEDGMENT OF LIMITED WARRANTY


By signing below, you agree that you have read this limited warranty in its entirety and understands its terms and conditions. You acknowledge that you have received a copy of this limited warranty at or before the time of the sale.

Purchaser's Name	Delivery Date	
Spouse's Name	Model	
Street Address	HIN	
City, State, Zip	Selling Dealer	
Email	Sales Representative	
Mobile Number	Original Owner	Second Owner
Where do you do your boating?		
Purchaser's Signature	Would you like to receive exciting updates from World Cat?	
Dealer Signature	Text	Email
Date		


Chapter 10: 235HB Diagrams

10.1 Thru-Hull Locations

A	Bilge Discharge
B	Livewell Discharge
C	Cockpit Discharge
D	Fishbox Discharge
E	Console Lounger Tub Discharge
F	Bow Tubs Discharge





Starboard Side



Port Side


10.2 Hose Plumbing

10.2.1 Fresh Water Plumbing (Option)




NUMBER	DESCRIPTION
1	PN: 30220001 WATER TANK
2	PN: 20160364 TANK ELBOW .75 MPT TO .625 HOSE BARB
3	PN20173797 .75 MPT PLUG
4	PN: 20160084 1.5 MPT TO 1.5 HOSE BARB ELBOW
5	PN: 20160267 .75 MPT TO .75 HOSE BARB ELBOW
6	20163882 TANK STRAP 17 X 10.5


10.2.2 Raw Water Plumbing




Raw Water Pump




10.2.3 Drain Plumbing



Aft Section



Mid-to-Fwd-Section




235HB BATTERY CABLE ROUTING

— POWER
— GROUND


PORT ENGINE

STBD ENGINE




235HB STEREO UPGRADE BATTERY CABLE ROUTING

— POWER
— GROUND



TRAILER DIMENSIONS (July 2026)



	235HB	235TE	230DC	230SD	240DC	265CCX	265DCX	280DCX	280CCX	295CC	296DC	325CC	325DC	400DC	400CC
A	22' 7"	22' 7"	22' 7"	22' 7"	24' 1"	25' - 6-1/4"	25' - 6-1/4"	27' - 5"	27' - 5"	29' 5/8"	29' 5/8"	32'-0 1/2"	32'-0 1/2"	37'-1"	37'-1"
B					23' 6"	24' - 11"	24' - 11"	26' - 10 5/8"	26' - 10 5/8"	28' 5"	28' 5"	31'-4 7/8"	31'-4 7/8"	36'-6"	36'-6"
C	38 1/2"	44 5/8"	40"	40"	51"	48 1/8"	50 1/4"	4' - 3 1/2"	4' - 3 1/2"	4' 3"	4' 3"	4'-6 5/8"	4'-6 5/8"	4'-2 3/8"	4'-2 3/8"
D	51 1/2"	51"	51"	51"	62 1/2"	64 7/8"	66 5/8"	5'-10"	5'-10"	5' 11"	5' 11"	6'- 3 5/8"	6'- 3 5/8"	6'- 3 5/8"	6'- 3 5/8"
E	34 3/4"	34 3/4"	34 3/4"	34 3/4"	34 3/4"	36 1/4"	36 1/4"	3' - 1 1/2"	3' - 1 1/2"	39 1/4"	39 1/4"	43 1/8"	43 1/8"	48 5/8"	48 5/8"
F	59 5/8"	59 5/8"	59 5/8"	59 5/8"	58 1/2"	62 1/2"	62 1/2"	64"	64"	67 1/2"	67 1/2"	76 1/4"	76 1/4"	85 7/8"	85 7/8"
G	24 3/4"	24 3/4"	24 3/4"	24 3/4"	23 1/2"	24"	24"	26"	26"	26 5/8"	26 5/8"	33 1/8"	33 1/8"	34 7/8"	34 7/8"
H	8' 6"	8' 6"	8' 6"	8' 6"	8' 6"	108"	108"	109" - 3/8"	109" - 3/8"	115"	115"	125 1/4"	125 1/4"	147 7/8"	147 7/8"
I	17"	17"	17"	17"	19 3/8"	19 5/8"	19 5/8"	20"	20"	21 1/4"	21 1/4"	21"	21"	20"	20"
J	23"	23"	23"	23"	22"	24 7/8"	24 7/8"	30"	30"	28 1/2"	28 1/2"	28 3/4"	28 3/4"	21 3/4"	21 3/4"
1	109"	105 5/8"	110"	107"	114"	118"	118"	115"	121"	123"	119"	122"	130 1/4"	126 3/8"	131 7/8"
2	92"	90"	91"	90"	98"	93"	93"	95"	100"	101"	99"	105 1/4"	108 5/8"	102"	108"
COG w/ Eng	87"	92"	103"	103"	102"	108"	108"	105"	106"	131 1/2"	131"	127"	146"	157"	159"

INCLUDES PULPIT. SUBTRACT 11 1/2" TO DETERMINE LENGTH TO PORT AND STBD STEM

I DIMENSION TAKEN AT THE TRANSOM

J DIMENSION TAKEN APPROXIMATELY 15' FROM THE TRANSOM


1 DIMENSION FROM KEEL TO HARDTOP TOP (no outriggers or electronics installed)

2 DIMENSION FROM WATERLINE TO HARDTOP TOP (no outriggers or electronics installed)




10.4 Systems Overview


Standard Speakers (Optional Speakers)




Hardtop



Components



Deck Lights



Chapter 11: Reference Material

Yamaha Technical Support:
(800) 889-2624
<https://yamahaoutboards.com>

Mercury Technical Support:
(920) 929-5040
<https://www.mercurymarine.com/>

Garmin Technical Support:
U.S. 913-397-0872 | 1-800-800-1020 Canada 1-866-429-9296
<https://support.garmin.com>



235HB System Locations

System	Location of pump/component	Steps for use
Raw Water System	Port aft motorwell compartment	1. Verify the seacock is open, located in the port aft bilge area. 2. Attach hose to the Raw water fitting located on the aft port wall. 3. Press switch on the dash labeled Raw water pump. 4. Control the flow of water, by the hose nozzle.
Livewell System	Port aft motorwell compartment	1. Verify the seacock is open in the port aft bilge area. 2. Use the supplied drain plug to plug the drain in the livewell. 3. Press the live well switch located on the dash. 4. Turn the regulator, to fill and flow the desired speed
Bilge Pumps	Port and Starboard Aft Bilge Areas	1. With the batteries on the “Bilge pump” switch at the dash will power the pumps. 2. With the batteries off there is a float switch located next to the bilge pumps in the port/ Stbd bilge areas that will power the pumps while away from the boat.
Fishbox Drain System	Directly underneath livewell tubs	1. Open fishbox lid and remove contents as needed. 2. Verify drain is clear of debris and run pump with water. 3. Rinse fishbox after use. 3. Allow water to drain overboard through the fishbox drain system.
Freshwater System (Option)	Inside console unit	1. Before leaving the dock, fill the water tank with water with the freshwater fitting on the port side transom, next to shower. 2. Turn on the freshwater switch at the dash. 3. Twist the shower nozzle in the stern of the boat to control the flow of water.

Fuel System	Fuel fills located on deck	1. Verify engines are off before fueling. 2. Open the appropriate fuel fill cap. 3. Fill slowly and do not overfill. 4. Secure fuel fill cap after fueling. 5. Check for fuel odor before starting engines.
Engine / Propulsion System	Twin outboard engines at transom	1. Verify battery switches are on. 2. Confirm engines are trimmed properly and the area around the props is clear. 3. Start engines per engine manufacturer instructions. 4. Operate shift, throttle, and trim controls from the helm. 5. Flush engines after use when required by the engine manufacturer.
Steering System	Helm steering wheel, steering helm, and outboard steering components on console unit	1. Verify batteries are on before operating. 2. Turn the steering wheel at the helm to control engine direction. 3. Check steering response before leaving the dock. 4. If steering feels stiff, loose, or unresponsive, discontinue operation and contact an authorized dealer.
Battery System	Battery switch panel on center transom seat.	1. Turn battery switches on before operating systems. 2. Use normal battery switch positions for standard operation. 3. Use emergency parallel only when additional starting power is needed. 4. Turn batteries off when the boat is not in use.

Replacement Parts

Brand: Shurflo
Model: 1700-020 031
WC Part #: 20740246001
Application: Shurflo 1100 Bait Sentry w/ Deutsch plug



Brand: Shurflo
Model: 4248-153-J09
WC Part #: 20740303000
Application: Shurflo Pro Blaster Water Pump w/Deutsch Plug



Brand: Xylem (previously ITT)
Model: 27DA-JNAAA
WC Part #: 20740347000
Application: BILGE, Pump, Standard, 1100 GPH



Brand: Xylem
Model: 40AD2M
WC Part #: 20740299000
Application: Rule-A-Matic Float Switch w/ Deutsch Plug



Brand: Navico
Model: BP4682B
WC Part #: 20740305000
Application: Whale Gulper Grouper MK 2 Diaphragm Pump w/ Deutsch Plug (4 hole)



Brand: Yamaha Parts
Model: QB1-10MAS-10-00
WC Part #: 90441543000
Application: Yamaha Fuel Filter/Water Separator



Brand: Attwood Corporation
Model: 5550-24S1
WC Part #: 20200389000
Application: Attwood LED Mast Light (24") - S/S Base



Brand: Marinco
Model: 6011B
WC Part #: 20173422000
Application: Blue Sea m-Series Battery Switch, Dual Circuit plus



Brand: Marinco
Model: 7548
WC Part #: 20174082000
Application: C-Series Breaker (80A)



Brand: ITC
Model: 69670B-SS-RGBW
WC Part #: 20200406000
Application: Hardtop Light, Flushmount, S/S Bezel (RGB)



Brand: Lumitec
Model: 101723
WC Part #: 20174312000
Application: Capri3 Flush Mount LED Flood Light



Brand: ITC
Model: 69600BE-SS
WC Part #: 20200413000
Application: Flushmount 3" Courtesy Light, (Cool White, Polished S/S)



Brand: Taco
Model: F38-6610D
WC Part #: 20164244000
Application: Taco Surface Mount Nav Light



Brand: Marinco
Model: 1045B
WC Part #: 20173580000
Application: USB Charging Receptacle (4.8A Fast Charge)



Brand: Pro Charging System
Model: RS2
WC Part #: 20174092000
Application: RealPro Series - Two Bank 6 Amp Per Bank



OPTIONAL

Brand: BlueWater Enterprises

Model: 77000-9900-040

WC Part #: 20174034000

Application: Circuit Breaker- Surface Mount 40A



OPTIONAL

Brand: JL Audio

Model: O-MV400/4i

WC Part #: 20174089000

Application: JL Audio 4 Channel, 400 Watt Mvi DSP Amplifier



[illegible]

Notes

[illegible]



WORLD CATTM
A BETTER WAY TO BOATTM

All rights reserved. All specifications and options are subject to change.
© 2027 WORLD CATTM | TARBORO, NC - GREENVILLE, NC | WORLDCAT.COM